



Fitting Instructions

TOWBAR **HN59Q**
For Honda Element
Dec 2002 -

MATERIALS

A	1	Cross Bar
D	4	M12 x 120 x 1.75 Bolts, Nuts, Lock washers and 2 off Flat Washers (30mm O.D).
E	4	Bush 19mm O.D, 91mm Long.
F	1	M16 x 100 x 2.0 Bolt, nut and Lock Washer.
G	2	Bush 40mm O.D, 22mm Long.
H	4	M12 Bolt caps.
ZQ	1	Detachable Neck (ZQ2070)

FITTING

1. Attach crossbar (A) to existing holes in chassis rails using fixings (D) and bushes (E).
2. Insert bushes (G) either side of towing eye and secure using bolt (F).
3. Attach neck (ZQ) as per separate fitting instruction using separate kit with bolt caps (H).

Note:

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

