



Fitting Instructions

TOWBAR F92AR
For FORD MONDEO
SALOON AND HATCHBACK
(2001-)

MATERIALS

A	1	Cross Bar
C	1	Right Hand Side Arm
D	1	Left Hand Side Arm
E	4	M10 x 110 x 1.5mm Bolts, Nuts, Lock Washers and Flat Washers (30mm O.D.)
E1	4	Bushes (17mm O.D. - 79mm long)
F	2	M10 x 45 x 1.5mm Bolts, Nuts, Lock Washers and 4 Flat Washers (20mm O.D.)
G	2	Spacer Plates
H	2	M12 x 40 x 1.75mm Bolts, Nuts and Lock Washers
R	1	Detachable Neck
EP	1	Electrical Plate
SC	1	Safety Chain Plate

FITTING

1. Remove plastic panel from underside of vehicle (3 large nuts). Release lower edge of bumper (4 large nuts on underside of bumper).
2. Lower exhaust and remove heat shield to gain access to the chassis rails. Insert Bushes (E1) on Bolts (E) with Large Flat Washers under bolt heads into the frame through the adjacent 'keyholes' and loosely attach Side Arms (C) and (D).
3. Cut bumper extension as shown below. **Note:** The bumper extension is available from Ford as a separate clip on item (part no. 1115579). **NOT ZETEC S.**
4. Pull down lower edge of bumper and insert Cross Bar (A). Loosely attach Cross Bar (A) to rear panel and Side Arms (C) and (D) using Bolts (F) at upper mountings and Bolts (H) with Spacers (G) on lower mountings.
5. Attach Detachable Unit (R) to Cross Bar (A) – please refer to ZR2 Detachable Towball System fitting instruction supplied – **Note:** Paragraph 1 of fitting instruction does not apply to this towbar. **Tighten all Bolts.**
6. Re-mount heat shield and exhaust. Re-mount lower bumper edge. Re-fit plastic panel.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

