

# FITTING INSTRUCTION

**VW3056A**  
Batch 000000

**Volkswagen Golf (Inc. Van/GTi/VR6)(Inc. Convertible 94-97)(not Driver)(not Convertible 84-94) 1984-1997 & Volkswagen Vento (not Cabriolet) 1992-98**

NOTE: THIS TOWBAR MUST NOT BE FITTED TO ANY LIGHT PASSENGER VEHICLE REGISTERED ON OR AFTER AUGUST 1ST 1998

COMPONENTS		
ITEM	QTY	DESCRIPTION
A	1	Towbar
B	2	Bumper Brackets

BOLT PACK		
ITEM	QTY	DESCRIPTION
C	2	M16 x 50 Bolts, Nuts & Washers
D	4	M12 x 35 Bolts & Washers
E	2	M8 x 20 Bolts, Nuts & Washers
F	4	M12 Heavy Duty Washers

## FITTING PROCEDURE

- ⇒ On pre 1991 models with deep plastic bumpers remove bumper and remove and discard mounting arms
- ⇒ Attach bumper brackets (B) to towbar (A) with bolts (E) refit towbar (A) and bumper using bolts (D) with heavy duty washers (F) under the heads
- ⇒ On models 1991 onwards remove bumper, four screws on top and three underneath, then remove caps on end of chassis rails and discard
- ⇒ Insert towbar (A) into chassis rails and attach with bolts (D) and heavy duty washers (F) under the heads
- ⇒ Mark out the centre line of the bumper and cut out section as shown in the bottom lip of the bumper
- ⇒ Replace bumper

## TIGHTEN ALL BOLTS

TORQUE SETTINGS ISO Coarse Pitch M8=29Nm, M10=58Nm, M12=102Nm, M16=252Nm  
ISO Fine Pitch M8=31Nm, M10=61Nm, M12=111Nm

**THE VEHICLE MANUFACTURER'S SPECIFICATION FOR THE TRAILER WEIGHT AND NOSE LOAD LIMITS MUST BE OBSERVED.**

## FITTING DIAGRAM

