



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 5

TT863 TOYOTA RAV 4 SWB/LWB 2000 - 2006 (WITH BUMPER STEP)

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	C	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Extension Bar	D	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
			E	6	M10 x 45 Bolts, Nuts & S/P Washers
			F	6	10 x 25 Flat Washers
			G	4	12 x 25 Flat Washers

1. Locate and remove the three existing bolts each side securing the step to each chassis bracket.
Note: The existing chassis brackets fit directly to the towbar mounting points in each chassis member. Check existing chassis bolts and torque up as required.
2. The existing 10mm spacers between the step and the chassis is removed and not refitted with the towbar.
3. Using Item E with Item F loosely re-fit the bumper step placing Item A between the bumper step and the chassis brackets.
4. Fully tighten all nuts and bolts.
5. Using Item D bolt Item G bolt Item B to Item A.
6. Using Item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts including the existing chassis bracket bolts and ensure the towbar and step are rigid and secure.



Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.