



Fitting Instruction

Towbar For
Dacia Jogger
2022 -

DA1440U

MATERIALS:

A	1	Crossbar
B	2	Sidearm
C	4	M12 x 45 x 1.75 mm Bolt & Washers (30mm OD / 8 total)
D	4	M12 x 35 x 1.75 mm Bolts & Nyloc Nuts
ZE	1	Electrical Plate
ZN	1	Chosen Neck

FITTING:

1. Remove the plastic inner wheel-arch covers to enable easier access to the chassis mounting points (torx screws & plastic fixings).
2. Remove the tape covering the mounting points on the outer face of each chassis. Under-seal may make locating the mounting holes more difficult. **Note:** it is essential that the holes and mating surfaces are fully clear of any under-seal compound and extrusions).
3. **Loosely** attach the Sidearms (**B**) to the outer chassis face using fixings (**C**), positioning one Washer between the Sidearm and the chassis at each mounting point.
4. Taking care not to damage the bumper **Loosely** attach Crossbar (**A**) between the Sidearms (**B**) using fasteners (**D**).
5. Correctly align the Sidearms and Crossbar and fully tighten fixings to their correct torque settings.
6. Attach neck option (**ZN**) in position and attach electrical plate (**ZE**) to centre profile holes using the separate fitting instructions provided.
7. Re-fit the wheel-arch covers.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M12 - 83 Nm, M16 - 200 Nm (Grade 8.8)

