



Fitting Instructions

TOWBAR
For Toyota Avensis Saloon 2009-

For use With 3012 Series Necks

TY157A-FIT
for
TY157A
TY157AQ
TY157AQF
TY157AS

MATERIALS

A	1	Crossbar
D	6	M12 x 35 x 1.25 Bolts and Flat Washers (25mm O.D.)
E	1	M6x 20 x 1.00 Bolt and Flat Washer
ZE	1	Flip up Electrical plate kit (Z99)
ZP	1	Angle Plate (ZEQ4)


For use with either

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

FITTING

1. Remove lower under tray and exhaust heat shield. (**Petrol models only**- lower rear silencer)
2. Remove lashing eye bolted to left hand chassis rail.
3. Loosely attach Cross bar (A) and **lashing eye** to vehicle chassis using Bolts (D). Fully tighten Bolts.
4. Refit exhaust heat shield (use longer bolt (E). Re-secure rear silencer .
5. Attach neck option and Flip up electrical plate (Z) (ZE).
6. Cut under tray as shown below and refit.

Recommended torque settings: Grade 8.8 bolts: M8 - 24Nm, M10 - 52 Nm, M12 - 80 Nm, M14 - 130 Nm, M16 - 200 Nm
Grade 10.9: M12 - 120Nm, M10 - 70Nm M8- 35Nm



W0001TY157AU-FIT\$010802220000