


QD4PR/FL



KammBar

Instructions




CITY CRASH (✓)


According to ISO/ PAS 11154:2006





KammBar Pro



KammBar Fleet




Fitting Kit




QD4PR/FL

1.




2.




x4

x4



3.



SA397
PS181




SA398
PS181





SA397
PS180

D




SA398
PS180





SA397
PS180

C



SA398
PS180




SA397
PS180


B




SA398
PS180





4.



SA397
PS181




SA398
PS181



SA397
PS180

E




SA398
PS180



SA397
PS180

D



SA398
PS180



SA397
PS180


C



SA398
PS180




5.




L2

6.




L3







7.




8.




1st - Ø 3mm
2nd - Ø 6mm
3rd - Ø 9mm






15a.




	Option 1: Use Rivet Gun & M8 XL Mandrel.
	Option 1: Benutzen Sie eine Nietpistole & einen M8 XL Zugdorn.
	Option 1 : Utiliser un pistolet à riveter et un mandrin M8 XL.
	Opzione 1: utilizzare una pistola per rivetti e un mandrino M8 XL.
	Opción 1: Use la remachadora y el cabezal M8 XL.
	Opcja 1: należy użyć nitownicy z trzpieniem M8 XL.
	Opție 1: Gebruik Klinknagelpistool & M8 XL Opspandoorn.
	1. opció Használjon szegecselő pisztolyt és M8 XL tűskét.
	Alternativ 1: Använd en nitpistol och en M8 XL borraradapter.
	Variant 1: Použijte nýťovací kladivo a trn M8 XL.
	Vaihtoehto 1: Käytä niittivasaraa ja M8 XL -tuurnaa.
	Alternativ 1: Bruk naglepistol og M8 XL-mandreg.
	Možnosť 1: Použite nitovací pištol a trn M8 XL.

15b.




	Option 2: Use Impact Driver. AC24 Sold separately.
	Option 2: Benutzen Sie einen Schlagschrauber. Der AC24 wird separat verkauft.
	Option 2 : Utiliser une clé à choc. AC24 vendue séparément.
	Opzione 2: utilizzare l'avvitatore a percussione AC24 venduto separatamente.
	Opción 2: Use el atornillador de impacto. La herramienta AC24 se vende aparte.
	Opcja 2: należy użyć wkreślarki udarowej; klucz AC24 dostępny jest do nabycia osobno.
	Opție 2: Gebruik Slagschroevendraaier. AC24 wordt apart verkocht.
	2. opció Használjon ütvefűrőt. Az AC24 külön vásárolható meg.
	Alternativ 2: Använd en slagbormaskin. AC24 säljs separat.
	Variant 2: Použijte přiklepový utahováč. AC24 se prodává samostatně.
	Vaihtoehto 2: Käytä iskuväännintä. AC24 myydään erikseen.
	Alternativ 2: Bruk slagskrutrekker. AC24 selges separat.
	Možnosť 2: Použite elektrický uťahovák. AC24 Predáva sa samostatne.

15c.




	Option 3: Use Socket Wrench AC24 sold separately.
	Option 3: Benutzen Sie den separat verkauften AC24 Steckschlüssel.
	Option 3 : Utiliser la clé à douille AC24 vendue séparément.
	Opzione 3: utilizzare la chiave a bussola AC24 venduta separatamente.
	Opción 1: Use la remachadora y el cabezal M8 XL.
	Opcja 3: należy użyć klucza nasadowego AC24 dostępnego do nabycia osobno.
	Optie 3: Gebruik de apart verkochte Dopsleutel AC24.
	3. opció Használjon csavarkulcsot. Az AC24 külön vásárolható meg.
	Alternativ 3: Använd hylsnyckel. AC24 säljs separat.
	Varianta 3: Použite nástrčný kľúč AC24, ktorý sa predáva zvlášť.
	Vaihtoehto 3: Käytä hylsyavainta AC24, joka myydään erikseen.
	Alternativ 3: Bruk pipenøkkel AC24 som selges separat.
	Možnosť 3: Použite nástrčný kľúč AC24, ktorý sa predáva samostatne.


16.




17.









18.




19.







26.




27.




28.




29.









30.




31.







38.



39.




40.






QD1PR/FL KammBar

Instructions




CITY CRASH (✓)


According to ISO/ PAS 11154:2006




KammBar Pro



SA421 x 1 ☐




SA397 x 1 ☐




SA398 x 1 ☐


KammBar Fleet




SA395 x 1 ☐



C04 x 2
optional upgrade




SA397 x 1 ☐




SA398 x 1 ☐


Fitting Kit




PS023 x 2 ☐



PS182 x 2 ☐



MS2080 x 2 ☐



FS109
(M8 x 90)
x 2 ☐



FW021 (M8)
x 4 ☐




FN006 (M6)
x 2 ☐




FT01 x 1 ☐


1.





2.



3.




SA397
PS182





SA398
PS182

4.




SA397
PS182



SA398
PS182


5.

L2




6.


L3




7.




8.




9.




10.




11.




12.



13.




14.





15.



16.

