


Parts List:

Part No:	Description:	Size:	Torque	Qty:
1	Crossbar			1
2	Coupling Packer			1
3	L/H Sidearm			1
4	R/H Sidearm			1
5	8 x bolts, + 2 x Nyloc Nuts, + 6 x Flat Washers (25mm OD) + 2 x Flat Washers (40mm OD) + 6 x Cage Nuts	M12 x 30 x 1.75	95Nm	8
6	4 x Bolts + 4 x Nyloc Nuts + 2 x Flat Washers (40mm OD) + 2 x Flat Washers (25mm OD)	M12 x 35 x 1.75	95Nm	4
7	Insert Strap			2
8	90° Bracket			2
9	Bolt + Nyloc Nut	M12 x 35 x 1.75	130NM	6
10	Electrics Plate			1
11	Towball Bolt + Lock Washer + Nut	M16 x 60 x 2.0	214NM	2

Fitting:



Fitting:

1. Remove the bumper. Do not discard the bolts - these will be re-used. Remove black rear bar from chassis mounts and discard.
2. Assemble the cage nuts (5) to Insert Straps (7) (See diagram above). Placing Insert straps (7) on the inside of each chassis rail, attach (but do not secure) sidearms (3) & (4) with bolts (6) and then bolts (5).
3. Attach, but do not secure, crossbar (1) to side arms (3) & (4) using bolts (9).
4. Attach, but do not secure, angle brackets (8) to sidearms (3) & (4) and crossbar (1) using bolts (5) & (6).
5. Tighten all bolts to recommended torque settings. (See table above).

Note: This towbar must be used with a Class A50-1 or A50-X towball, which dimensionally conforms to A50-1 with a 'D' & 'S' value greater than or equal to that of the towbar.

****Manufacturers towing limits must be observed for towing capacity****