

MATERIAL

A	1	Cross Bar
B	1	Coupling Packer
F	8	M12 x 110mm, Bolts, Ø40 Flat Washers and Nyloc Nuts
CB	2	M16 x 60mm Coupling Bolts, Nuts, Lock Washers
EP	1	ZEP35 Electrical plate

Note: This towbar must be used with either a Witter Towball (part number Z11, Z32, Z46 and F40) or Class A50-1 or A50-X towball, which dimensionally conforms to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which must be observed.

FITTING

1. Remove and discard the towing eye from the right hand chassis rail.
2. Loosely attach Cross bar (A) to existing bushed holes in vehicle chassis using Bolts F with Flat Washers and Nyloc nuts.
3. Torque all bolts to values listed below.

Recommended torque settings:

Grade 8.8 bolts: M16 - 200 Nm.
Grade 10.9 bolts: M12 - 130 Nm

